

# UAT™

## *Universal AudioCast Transmitter*

Universal AudioCast Transmitter – For use with all Soundcast receivers, including iCast, SpeakerCast and OutCast. The UAT is a multi use wireless transmitter using the Soundcast 2.4GHz patented technology. It has a two-position latency switch for same room or other room or location applications; one line-level L/R RCA input jack set, one line-level mini jack output, an input sensitivity switch, one USB input and an external power supply (wall wart). Maximum range – Up to 350 feet with internal antenna. The UAT has USB Audio structure to control basic functions of track forward, track back, pause/play for commonly used media players through USB connection to PC. Switches between two inputs automatically with USB audio input taking higher priority.



UAT will support operation with all major media players in a seamless fashion that requires no drivers or software.

Specific compatible media players include:

- iTunes 4 and Higher
- Windows Media Player 9 and Higher
- MusicMatch 9.0 and Higher
- RealPlayer 10 and Higher
- WinAmp 5 and Higher

The Universal AudioCast Transmitter can operate off the USB power provided by the USB connection to the computer - making it completely portable for laptop use, or it can operate off the voltage from the included AC adapter. The variable latency allows the use of receivers in the same room for rear channel use. The variable sensitivity makes this unit compatible with nearly any source including computers, DVD players, AV receivers, and CD changers.

## SubCast™

### *Wireless subwoofer kit*

A combination of the Soundcast AudioCast Universal Transmitter and a new subwoofer receiver with internal antennas to broadcast the LFE signal from a home theater receiver or processor to any powered subwoofer via a wireless link. This will allow subwoofer placement anywhere in the listening area without running wires across the floor. All cables and connectors needed are included in the package.

